CALDECOTE FARM

NEWPORT PAGNELL . MILTON KEYNES

APPENDIX 10

ENVIRONMENTAL STATEMENT

AIR QUALITY

APPENDIX 10.3 MITIGATION



APPENDIX 10.3 IAQM HIGHLY RECOMMENDED MITIGATION MEASUES FOR SITES WITH A LOW RISK OF DUST IMPACTS

Communications

- Display the name and contact details of person(s) accountable for air quality and dust issues on the site boundary. This may be the environment manager/engineer or the site manager.
- Display the head or regional office contact information.
- Develop and implement a Dust Management Plan (DMP), which may include measures to control other emissions, approved by the Local Authority. The level of detail will depend on the risk, and should include as a minimum the highly recommended measures in this Appendix. The DMP may include monitoring of dust deposition, dust flux, real-time PM₁₀ continuous monitoring and/or visual inspections.

Site Management

- Record all dust and air quality complaints, identify cause(s), take appropriate measures to reduce emissions in a timely manner, and record the measures taken.
- Make the complaints log available to the local authority when asked.
- Record any exceptional incidents that cause dust and/or air emissions, either on- or
 offsite, and the action taken to resolve the situation in the logbook.

Monitoring

- Undertake daily on-site and off-site inspection, where receptors (including roads)
 are nearby, to monitor dust, record inspection results, and make the log available to
 the local authority when asked. This should include regular dust soiling checks of
 surfaces such as street furniture, cars and window sills within 100m of site
 boundary, with cleaning to be provided if necessary.
- Carry out regular site inspections to monitor compliance with the DMP, record inspection results, and make an inspection log available to the local authority when asked.

Increase the frequency of site inspections by the person accountable for air quality
and dust issues on site when activities with a high potential to produce dust are
being carried out and during prolonged dry or windy conditions.

Preparing and Maintaining the Site

- Plan site layout so that machinery and dust causing activities are located away from receptors, as far as is possible.
- Erect solid screens or barriers around dusty activities or the site boundary that are at least as high as any stockpiles on site.
- Fully enclose site or specific operations where there is a high potential for dust production and the site is actives for an extensive period.
- Avoid site runoff of water or mud.
- Keep site fencing, barriers and scaffolding clean using wet methods.
- Remove materials that have a potential to produce dust from site as soon as
 possible, unless being re-used on site. If they are being re-used on-site cover as
 described below.
- Cover, seed or fence stockpiles to prevent wind whipping

Operating Vehicle/Machinery and Sustainable Travel

- Ensure all vehicles switch off engines when stationary no idling vehicles.
- Avoid the use of diesel or petrol powered generators and use mains electricity or battery powered equipment where practicable.
- Impose and signpost a maximum-speed-limit of 15 mph on surfaced and 10 mph on unsurfaced haul roads and work areas (if long haul routes are required these speeds may be increased with suitable additional control measures provided, subject to the approval of the nominated undertaker and with the agreement of the local authority, where appropriate).

Operations

 Only use cutting, grinding or sawing equipment fitted or in conjunction with suitable dust suppression techniques such as water sprays or local extraction, e.g. suitable local exhaust ventilation systems.

- Ensure an adequate water supply on the site for effective dust/particulate matter suppression/mitigation, using non-potable water where possible and appropriate.
- Use enclosed chutes and conveyors and covered skips.
- Minimise drop heights from conveyors, loading shovels, hoppers and other loading or handling equipment and use fine water sprays on such equipment wherever appropriate.
- Ensure equipment is readily available on site to clean any dry spillages, and clean
 up spillages as soon as reasonably practicable after the event using wet cleaning
 methods.

Waste Management

Avoid bonfires and burning of waste materials.